

# 3i/7i

## White Glove Service Set-Up Guide

SNAP THIS QR CODE TO WATCH  
A QUICK SET-UP GUIDE VIDEO



3i



7i

### Step 1: Unpack



Your StreetStrider comes folded and assembled. Included is the Owner's Manual, tool kit, spare inner tubes and any additional accessories ordered. If ordered, the indoor trainer stand will arrive in a separate box fully assembled.

Remove the support boxes, lift the folded StreetStrider out of the box and place it on the floor. Remove packing materials, and locate the Owner's Manual, spare parts, and bundle items.

### Step 2: Unfold



Raise the head tube while sliding the Quick Release (QR) clamp T-pin to the right. With the head tube in the full upright position, allow the QR clamp T-pin to insert into the hole. Rotate the QR stem to the vertical position so that the lever is against the head tube, then close the lever downward onto the shoulder.



STREETSTRIDER

## Step 3: Reposition the Left Crank Arm



Rotate both crank arms to the 6 o'clock position, lift the QR lever on the left crank arm to the horizontal position, rotate the lever 180 degrees, and lower it to the left side of the crank arm.

Pull the left crank arm outward so that it just clears the end of the rectangular block. Rotate the right crank arm 180 degrees to the 12 o'clock position. Slide the left crank arm back onto the block to full insertion.

Lift the QR lever to the horizontal position, rotate it 180 degrees, then close the lever. Finally, squeeze the brake levers to release the parking brakes.

---

## Step 4: Enjoy Your StreetStrider

